



## How to upload TConfig.exe to TCG120/TCG140 controllers

TConfig.exe tool is used for configuration of TCG controllers. After connecting the TCG unit to the computer with a USB cable, it is recognized as a mass storage device and TConfig tool can be run directly from the controller.

In rare cases, the file may be corrupted, making the controller configuration impossible. To upload a working TConfig.exe file, please follow the steps below:

1. Turn OFF the power supply and disconnect the USB cable from TCG controller.
2. Press and hold the reset button
3. Connect the USB cable. Both leds will turn ON and then turn OFF. When both LEDs turn ON for the second time, release the reset button.
4. The controller should be recognized as USB storage device. Open Windows Explorer, format the mass storage device and rename it to "TCG120" (TCG120-4) or "TCG140" (TCG140-4) . After the format procedure is finished you can copy the TConfig.exe tool. (TConfig.exe can be downloaded from <https://www.teracomsystems.com/download/tconfig/> . Please extract the file before copying to TCG memory.)
5. Reconnect the USB cable and connect the power supply. The device will be recognized as a write protected storage device.
6. You can start the TConfig tool.