

Combination Ladder User Manual (KTY)

Segment hook in place



Segment lock (closed)



Segment lock (closed)



The segment hooks are used to adjust ladder height step by step. The segment lock is used to lock the ladder at the desired height, so that the ladder can be moved and lifted.

Segment lock (open)



Segment hook not in place



Before climbing onto the ladder, you must always check that the segment hooks are properly in place and that the segment lock is closed, as shown in the pictures above.

Photos on the left:

When the segment lock is open, the segment hook can be moved freely to adjust ladder height.

Before use, you must always make sure that the ladders' top guides are placed correctly and that the ladder stiles pass through them as shown in the picture.

Top guide from the inside



Top guide from the outside



In combination ladders, the top guides are equipped with hinges (see photos below) that allow the ladder to be used as a trestle ladder. It is important that the hinge pin is correctly placed in its slot when the ladder is used as a trestle ladder.

*Hinge pin correctly in its slot
It is safe to use the ladder!*



*Hinge pin incorrectly placed
Do not climb onto the ladder!*



*Hinge pin incorrectly placed
Do not climb onto the ladder!*



Limiting strap is loose.

Do not climb onto the ladder!



Limiting strap is tight.

It is safe to use the ladder!



Only climb onto the ladder from the front side of the ladder, otherwise the steps will not be at the correct angle in relation to your feet. In the picture you can see how the steps are tilted towards the user when standing in front of the ladder.

The segment lock and segment hooks are also attached to the front of the ladder, as seen in the picture.