



Vinkli 2, Tartu
51014, Estonia
+372 5666 7699
info@huum.eu

huum.eu
#huumsauna

TILKOBLINGSINSTRUKSJONER **WIRING INSTRUCTIONS**

Utvidelsesboks til UKU saunakontroller
Extension box for UKU sauna controller

NO

UKU extension box (EU) for HIVE varmeapparater 230V 3~, 2x63A, 50Hz

NB! Hovedmodul og utvidelsesmodul må kobles til separate sikringer.

Brukes med alle kontrollermodeller **UKU Wi-Fi**, **UKU GSM** og **UKU Local**. Denne installasjonstegningen erstatter installasjonstegningen i UKU-håndboken.

Følgende skjema brukes til å koble til en varmeapparat over 10,5 kW (HIVE 12, 15 og 18 kW). Fest enheten til veggen med 4 skruer.

Plassering

Utvidelsesboksen må plasseres utenfor damprommet, i nærheten av UKUs hovedmodul.

Finn de siste oppdateringene på vår webside www.huum.eu

EN

UKU extension box (EU) for HIVE Heaters 230V 3~, 2x63A, 50Hz

NB! Main module and Extension Box must be connected to separate circuit breaker.

Only used with controller models **UKU Wi-Fi** and **UKU Local**. This installation drawing replaces the installation drawing in UKU manual.

The following scheme is used to connect the heater over 10,5 kW (Hive 12, 15 and 18 kW). Fix the unit to the wall with 4 screws.

Placement

The extension box has to be located outside the steam room, near UKU main module.

Find the latest updates on our webpage www.huum.eu

